

Enamel Camping Mug – White/Purple, White/Grey
Object Enamel Hook Mug
Item Code: 80340804 (grey), Item Code: 80340805 (purple)

Please read these precautions before use and store it carefully after reading. Improper handling may lead to accidents.

Instructions for use

Before using for the first time, please check that there are no defects on any parts such as deformation or rattling.

Before using for the first time, wash the entire product thoroughly.

Installation of lid and handle

Fill the cup with your drink and push the lid on firmly to fit it to the top of cup. Be sure to use the cup with the included lid and don't replace it with another type.

Slide the wings of the handle all the way into the lip at the top of the cup with the lid on, making sure it is not loose before using.

Do not remove the lid while gripping the handle. This may cause the handle to break or the cup to tip over.

When putting hot coffee, tea or other hot drinks into the cup and using it, please be careful not to touch the cup body directly to avoid the risk of getting burned.

▲ Handling precautions

- This product comes with a lid to prevent drinks from spilling if the mug falls over. It does not guarantee to insulate the drink or prevent it from going cold.
- Not compatible with induction hobs or microwave ovens. Do not place it on top of a stove as this is dangerous.
- Take care when using hot liquids or handling the hot mug. Use an oven mitt or something similar.
- Do not subject the product to strong impacts such as hitting it hard or dropping it on the floor.
- When washing, remove the lid and handle and wash them separately. After washing, wipe the cup and handle thoroughly with a dry cloth to remove any moisture.

- Do not use abrasives, nylon scrubbers, metal scrubbers, etc. They may cause scratches or other damage.
- Do not use for anything other than the intended use as it may cause damage or be dangerous.
- Enamel glaze is inorganic and does not contain any ingredients that are harmful to the human body. Even if rust occurs, iron rust (iron oxide) is not harmful to the human body. If it occurs, it can be removed by washing with a soft sponge.

▲ Care instructions

- To clean, use a neutral dishwashing detergent and a soft sponge.
- Please do not use in a dishwasher.
- Do not scrub with hard sponges or scrubbing pads, or use abrasives or cleansers as they will damage the enamel surface.
- There is a magnet inside the handle, so after washing, be sure to wipe off any water with a dry cloth.
- After washing, be sure to wipe off any water with a dry cloth to prevent rust on the end faces. The edges are difficult to apply enamel glaze to, so there is a possibility that some rust may occur in this area.
- Do not soak the cup in water as this may cause rust. If you wipe off water and dry the product well after use, you can minimize the occurrence of rust.

▲ Specification

Product size:

Enamel cup: 9.4cm diameter × 10cm high

With handle and lid attached: 13cm wide × 9.4cm depth x 10.5cm high

Capacity: 360ml/240ml

Materials:

Surface treatment: Enamel

Material type: Enamel steel plate (iron) thickness 0.8mm, ABS, silicon, magnet, PP

Enamel cup 170g

Lid (with silicon) 30g

Handle (with neodymium magnet) 20g

Manufacturer contact information

Hearth Designs Co., Ltd.
2-19 Rinku Minamihama, Sennan City,
Osaka Prefecture, 590-0535
TEL: 072-485-3638/FAX:072-482-6135

Imported by

Hatsukoi.co.uk
22 Slait Hill, East Cranmore, Shepton
Mallet, Somerset BA4 4LL
United Kingdom
contact@hatsukoi.co.uk

EU responsible (for authorities only)

eucomply OÜ
Pärnu mnt 139b-14 11317 Tallinn,
Estonia hello@eucompliancepartner.com
+3375690241